
How to change the Windows8 system language

Prepare : USB keyboard x1, OTG cable x1 or USB HUB x1, Windows8 adapter(charger) x1, Micro-SD card or USB disk x1 (The Micro SD or USB disk must be good quality, must be original instead of any fake Brand, and at least 2GB free capacity)

- 1) Download the zipped parcel named "Windows8.1 language package" from www.reachgoodsoft.com, unzip it, and copy all the folders and files to the root of the Micro-SD card or USB disk. For the folders or files, please refer to the following Fig1.





Fig. 1

- 2) Connecting the Windows tablet PC with charger, kept it being charged during the whole operation, to avoid Tablet PC turning off.
- 3) Connecting the Micro-SD card or USB disk with the PC, power on the PC, double click "this PC", to check if the PC recognize the Micro-SD card or USB disk. If PC fails to recognize the Micro-SD card or USB disk, change a new one.
- 4) Connecting USB keyboards with the PC via the OTG cable or USB HUB.

On the keyboards, press "Win" key and "X" key at the same time. (**Notes : Some keyboards maybe print  for the "Win" key**), choose and click "Run", in the pop-up Windows, input


command "LPKSETUP" (**Notes : input LPKSETUP by lowercase letters.**) , press "enter" key on the keyboards, Tablet PC will pop-up a new Windows.

5) In the newly pop-up Windows, choose "Installing display language" .

6) Click "Explore" , find and choose the target language package from the USB disk or Micro-SD card.

For example: the default OS language is English, you want to change it into Russian. Click "Explore" , choose the USB disk or Micro-SD card, open the folder named "ru-ru" , select the file named "lp" .

After you set path, it takes about 2~10 seconds for the PC to get the Path. Afterwards, following the instruction displayed on the screen to finish it. While the new language package is installed successfully, re-start the PC.

7) After re-starting PC, touch  button on the touch panel, to back to the Windows Home. On the touch panel, slide your finger from the right edge to left, to slide out 5 menus on the right side, the bottom one is "Setting" . Touch "Setting" , touch "Change PC settings" (displayed at the bottom line), touch "Time and language" , at first let us set "Date and time" , then let us set "Region and language" , choose your target country name in the "Country or region" , and in the "language" column, touch "add language" , in the pop-up Windows, slide the touch panel, find and select your target language.

8) At last, restart your PC. By now, the System language are changed successfully.

Remarks :

1) Without installing new language package, by only setting the foresaid setp7, you can only change the keyboards setting, but can' t change the system language.

2) If want to restore to the default OS language or delete any language package, starting from the

aforesaid Set4, in the Setp5, choose “uninstall display language” , in the pop-up Windows, select the target language you want to delete, then follow the instruction to finish it.(**Notes :You can delete the default OS language.)**

3) So far, there are 37 different language packages, for details, please refer to the above Fig.1.